XCam[™]II Battery Pack

- Turns your XCam II into a PartyCam[™]
- Lets you take your XCam II anywhere.
- Uses four AA alkaline batteries.
- Lasts up to four hours.

The XC10A camera is normally powered from a small plug-in AC power supply. But with the new ZB10A battery Pack you can now take your XCam II anywhere. Use it at parties, barbecues, or anywhere you like. The battery pack accepts 4 AA alkaline batteries to give you 4 hours of fun.

- 1. Open the lid on the base of the battery pack.
- 2. Insert four AA alkaline batteries. Observe polarity.
- 3. Pass the jack from the camera through the hole in the battery pack.
- 4. Coil the wire neatly inside, avoiding the screw bosses.
- 5. Screw the camera onto the battery pack, taking care not to trap any wire.
- 6. Plug the jack from the battery pack into the camera.
- 7. Refer to the setup and operating instructions that came with the XCam II camera system for camera setup and operation.


X10 (USA) INC. LIMITED 1-YEAR WARRANTY

X10 (USA) Inc. warrants X10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X10 (USA) Inc. agrees to repair or replace, at it's sole discretion, a defective X10 product if returned to X10 (USA) Inc. within the warranty period and with proof of purchase.

If service is required under this warranty:

- 1. Call 1-800-675-3044 or visit www.x10.com, or e-mail sales@x10.com to obtain a Return Merchandise Authorization (RMA) number.
- 2. Return the defective unit postage prepaid to X10 (see address on back).
- 3. Enclose a check for \$4.00 to cover postage and handling.
- 4. Enclose a dated proof of purchase.
- 5. X10 is not responsible for shipping damage. Units to be returned should be packed carefully.

Please visit www.x10.com/warranty to complete your on-line warranty registration. Thank you.





ZB10A-9/01