

## Using QEES Wall and QEES Ring to activate scenes On the Vera controller

- 1) Bring the QEES Wall / Ring to the Vera controller.
- 2) In the Vera GUI click "Add Z-Wave controller".
- 3) Briefly press the service button 3 times on the QEES Wall / QEES Ring.
- 4) Wait for Vera to complete the inclusion process, then go back to The device screen.





- 5) Assign name / description to the newly added Z-Wave controller, and select the room which the device will be installed in.
- 6) Make sure the Automatically configure option is set to "Yes".
- 7) Click "Save" in the Vera GUI.



- 8) Go back to the Device screen and expand the settings for the newly added QEES Wall / QEES Ring by clicking on the "+".
- 9) Mark the check box "Treat scene buttons as events".
- 10) Click "Save" in the Vera GUI.
- 11) Wait 1 or 2 minutes for the Vera controller to save and reload the changes made.
- 12) Send a node info message from the newly added QEES Wall / QEES Ring by briefly pressing the service button, followed by holding down the service button.

13) In the Vera GUI navigate to the Scenes screen.



14) Create an event as shown above. For the QEES Wall and QEES Ring, button number could be 1-4.